

TP4 : Computer Vision

Aurélien Bernier Levalois & Yoann Fleytoux

Report : Part 1


%See TP4_1.m for details of answers

It is intended to carry out the calibration of a chamber by doing the calculation of the matrix Of projection. The calibration process integrates the following steps:

1. Acquire the coordinates of the calibration points belonging to different planes of Calibration.


Note: The 3D coordinates can be obtained by the user manually. The 2D coordinates are to be obtained in the image by calculating the center of mass of the rectangles / squares placed in a calibration plane. The calibration pattern may consist of an equally spaced rectangle / squared array. The distance between the centers of the rectangles / squares must be known precisely. Consider the top left-hand point coincident with the origin of the OBJECT coordinate system, and the X and Y axes of the frame aligned with the rows and columns of the rectangle / squares matrix. Get the 3D coordinates of the Rectangles /

Points of A1 (blue) and A2 (red) on top of A1



squares

Points of A1 (blue) and A2 (red) on top of A1



2. Fill in the matrix A once the coordinates $[X_w, Y_w, Z_w]$ and $[x_f, y_f]$ of each of the points considered for calibration are known. Must use points that belong to more than one plane.

Note: The coordinates $[x_f, y_f]$ are obtained by calculating the centers of mass in the image.

3. Calculate the pseudo-inverse matrix of A .

4. Calculate the elements of matrix M, considering $M_{12} = 1$

5. Once the perspective matrix M is known, project the 3D calibration points into Image ($p = M \cdot P_w = [x_f, y_f]$), and compute the disparity in the image. The disparity is calculated for each point through

$$D = \sqrt{(x_f - x'_f)^2 + (y_f - y'_f)^2}$$

6. Calculate the maximum, minimum, median, mean and standard deviations.

This parameter is a good indicator of the quality of the calibration performed and "also" of the quality of the calculated model parameters. A perfect calibration gives zero mean disparity, that is, all points projected on the image coincide with those calculated through the perspective matrix.

```
minD =  
0.0064
```


```
meanD =  
0.2348
```

```
|  
medD =  
0.1976
```

```
stdD =  
0.1680
```

```
maxD =  
0.6822
```

7. Display a histogram of disparity values.



2a parte - 2nd part

See TP4_2.m

Results with A1_2

1 - In calculating the matrix M instead of imposing the constraint $M_{12} = 1$ use the decomposition in Singular values as described in the theoretical class;

M =

0.0380	-0.0002	-0.0045	-0.6763
0.0015	0.0403	0.0015	-0.7345
0.0000	0.0000	-0.0000	0.0068

2- Calculate the intrinsic and extrinsic parameters (from matrix M) as described in the theoretical class;

K =

0.0383	0	0.0000
0	0.0404	0.0000
0	0	1.0000

R_T =

0.9932	-0.0064	-0.1165	-17.6788
0.0378	0.9986	0.0374	-18.1990
0.0000	0.0000	-0.0000	0.0068

3- Calculate the maximum, minimum, median, mean and standard deviation differences as in part 1.

minD =

0.0056

meanD =

0.2342

medD =

0.1912


stdD =

0.1687

maxD =

0.6846

4-Present a histogram of the disparity values.



5-Calculate the intrinsic and extrinsic parameters using the QR decomposition. Compare the results with those obtained in the previous paragraphs and make a critical analysis.

Q =

-0.9992	0.0401	-0.0000
-0.0401	-0.9992	-0.0001
-0.0000	-0.0001	1.0000

R =

-0.0380	-0.0014	0.0044	0.7053
0	-0.0403	-0.0017	0.7067
0	0	-0.0000	0.0069

We can see that both $M=K \cdot R_T=Q \cdot R$ and that R and K are quite similar (if we consider the absolute value).

3a parte - 3rd part


%See TP4_3.m for details of answers

Now consider the images "proj_image_i.jpg" (i = 5 ... 13). The side of each square measures 38 mm.


A) Calibrate the camera that acquired these images using the following Matlab functions:

- "detectCheckerboardPoints";
- "generateCheckerboardPoints";
- "estimateCameraParameters";

B) Use the "showExtrinsics" function to represent the location of the pattern in the Camera coordinate system and to represent the camera in the Coordinates of the two patterns;



C) Use the "showReprojectionErrors" function to determine the histogram of reprojection



D) Use the code you developed in Part 2 and compare the calibration results.

cameraParams.RotationMatrices

ans(:,:,1) =

```
    0.7281 -0.1069    0.6770
    0.0833 0.9942 0.0675
   -0.6804    0.0072 0.7328
```

ans(:,:,2) =

```
    0.8650 -0.0377 -0.5003
   -0.2054    0.8832 -0.4216
    0.4578 0.4675 0.7563
```

ans(:,:,3) =

```
    0.9783 -0.1079 -0.1768
   -0.0539    0.6915 -0.7204
    0.2000 0.7143 0.6707
```

ans(:,:,4) =

```
    0.8274 0.1583 -0.5388
   -0.1011    0.9858 0.1343
    0.5524 -0.0566    0.8317
```

ans(:,:,5) =

```
    0.9950 -0.0526    0.0846
    0.0891 0.8495 -0.5200
   -0.0445    0.5250 0.8500
```

ans(:,:,6) =

```
    0.9179 0.1691 -0.3589
   -0.2861    0.9089 -0.3035
    0.2749 0.3813 0.8826
```

ans(:,:,7) =

```
0.9721 -0.2332 -0.0261
0.2231 0.9531 -0.2042
0.0725 0.1927 0.9786
```

```
ans(:,:,8) =
```

```
0.9576 -0.0221 -0.2873
-0.1417 0.8320 -0.5364
0.2509 0.5544 0.7936
```

```
ans(:,:,9) =
```

```
0.9866 -0.0089 -0.1632
-0.0189 0.9856 -0.1679
0.1623 0.1688 0.9722
```

```
cameraParams.FocalLength =
```

```
1.0e+03 *
```

```
2.0732 2.0706
```

```
cameraParams.IntrinsicMatrix =
```

```
1.0e+03 *
```

```
2.0732 0 0
0 2.0706 0
0.6900 0.5690 0.0010
```